



eastwestdesigns

## Assembly Instructions – Alpha 6

**Note: Because of the weight of the head end and completed assembly we suggest that assembly of an Alpha 6 is undertaken by two people.**

Position the head end of the bed approximately where it will finally sit allowing 1 metre clear space on one side.

With the head end sitting flat on the floor, attach the side rails and foot end.



The side rails are attached to the head and foot end by allen headed screws as shown. The screws are fitted to the top and bottom holes of the bracket.



Lifting from the head end, roll the head/rail assembly on its side.



Using the long screws supplied, attach the leg mounting blocks into the 4 corners making sure that the blocks are fitted square into the corners.





eastwestdesigns

## Assembly Instructions – Alpha 6 - page 2

Using the shorter screws supplied, attach the head end pedestal (black box assy) to the underside of the head end midway from side to side and front to back.

Attach two legs into the corner blocks away from the floor and finger tighten the nuts.

Remove the transit cleats from the underside of the head end.



Carefully roll the assembly back down. It will sit on the head end pedestal and the two legs.

Attach the two remaining legs by lifting the end and side as needed to access the leg mounting blocks.

Tighten all four legs into position.

Move the completed assembly into its final position.

**NB. Don't drag the frame by the foot end as this could damage the head end leg mounts.**

Fit the centre rail into position making sure the rail is pushed hard down into the brackets.

Attach slats/shoes. If fitting Pivotech flexible slat system the slats fitted with the curve upwards.

